



# WORKING WITH TRUECORE<sup>®</sup> STEEL

### **SERIES: MAKING FRAMES AND CORNERS**


### MAKING UP NOGGINS AND STUDS



Notching noggins. If you need to notch out a noggin, use a ruler or template to mark out the line to be cut. We recommend you use tin snips to cut out a noggin. See Hand cutting light gauge steel with tin snips.



Using your left or right offset snip, notch out the return lips. These are small sections and will peel away easily.



Use the left cut snips to cut in on the corner.



With the same snips, cut along the line to the opposite corner. Then use the right cut snips to cut into that corner.



Finally, cut back into the other corner to finish the notch.



**Using a vice grip.** A vice grip tool can be used to reduce cutting.



Using your left or right offset snip, notch out the return lips. These are small sections and will peel away easily.



Using your snips, cut away the web from the flanges.



Then use the vice grip tool to fold down the web.

PAGE 1 OF 2

**WORK SAFELY WITH STEEL** BlueScope recommends safety precautions are taken when working with steel – protect yourself with long sleeves, steel-capped boots, gloves and safety glasses and ensure you have the right tool for the job.





# WORKING WITH TRUECORE<sup>®</sup> STEEL

#### **SERIES: MAKING FRAMES AND CORNERS**

### MAKING UP NOGGINS AND STUDS



**Using templates.** Use a pre-made template to mark out the notch and fold lines. A template helps speed up the process and makes the job of cutting easier.



**Notching lip C-channel plates.** Notching lip C-channel plates to insert a stud can be done easily by using left and right cut snips.



First, mark the location of the stud insert.



Then use both left and right snips to cut out the material on both lips.



A **flattening tool** can be used to further speed up stud and base plate connections.



It is a simple tool that is used to flatten the lip as opposed to cutting it out, saving time on the job.



Using this tool you only have to mark the location of the stud then flatten the lips of the base plates, insert the stud and the job's done ready for fixing.

#### PAGE 2 OF 2


**WORK SAFELY WITH STEEL** BlueScope recommends safety precautions are taken when working with steel – protect yourself with long sleeves, steel-capped boots, gloves and safety glasses and ensure you have the right tool for the job.

FOR MORE INFORMATION VISIT TRUECORE.COM.AU OR CALL BLUESCOPE STEEL DIRECT ON 1800 738 576 The information and advice contained in this guide is of a general nature only and has not been prepared with your specific needs in mind. You should always obtain specialist advice to ensure that the materials, approach and techniques referred to in this guide meet your specific requirements. BlueScope Steel Limited makes no warranty as to the accuracy, completeness or reliability of any estimates, opinions or other information contained in this guide and to the maximum extent permitted by law, BlueScope Steel Limited direct from this Builetins all liability and responsibility for any loss or damage, direct or indirect, which may be suffered by any person acting in reliance on anything contained in or omitted from this Bulletin. TRUECORE®, BlueScope and the BlueScope Steel Limited ABN 16 000 011 058. All rights reserved.

## 75mm noggin notch

IMPORTANT: Refer to scale (cm) drawing above to ensure template is viewed at actual size. Recommended print size A3.

1 2 3 4 5





### 90mm noggin notch

IMPORTANT: Refer to scale (cm) drawing above to ensure template is viewed at actual size. Recommended print size A3.

1 2 3 4 5c

